

AEROSOL DISPENSER CONTROLLER PA-X



**ELECTRONIC
MANOMETER**

AEROSOL PRESSURE CONTROLLER PA-X

ELECTRONIC PRESSURE GAUGE



FUNCTION

The PA-x is an electronic pressure gauge adapted to the different aerosol sprays tips, to know the pressure of the push gas during the manufacturing of aerosol products.

3 adapters are supplied for standard aerosols.

A console XA version P (pressure) allows to read the value of the pressure inside the aerosol under test. A simple pressure of the aerosol chimney in the adapters allows to obtain the result on the screen.



TECHNICAL INFORMATION

Measurement modes	Peak and tracker
Memory	Storage of 200 values in the device
Measured pressure	Thrust pressure measurement up to 10 bar
Units	Bar, Psi
Sensor	Flush diaphragm pressure sensor
Accuracy	1% of EM
Power supply	On 12V electric battery with 220V charger included - EU plug
Connectivity	RS232 Port
Dimensions	L170xW250xH75 mm
Weight	2,7 kilos
Guarantee	1 year

OPTIONS

Matrix printer
Câble PC RS232 ou RS232-to-USB
DataXport® software to export data as it is received to any PC software
Customized adapters for specific aerosols
Calibration certificate connected to COFRAC up to 10 bars
Annual calibration in the ACRN metrology laboratory

DELIVERED WITH :

- Transport Case
- Charger
- 3 adapters for standard aerosols on the market (1 Male, 1 Female diam 4mm, 1 Female diam 3.4mm)
- Calibration certificate connected to COFRAC up to 9 bars